



FIG.1 CRANKCASE. / GEAR ASSY, GOVERNOR. (E01)




REF.NO.	PART NO	DESCRIPTION	Q'TY
E01-1	11310-Z140420-0000	CRANKCASE SUBASSEMBLY.	1
E01-2	37060-Z010120-0000	SENSOR, ENGINE OIL	1
E01-3	16400-Z010110-0000	GEAR ASSY, GOVERNOR	1
E01-4	16061-Z010110-0000	ARM, GOVERNOR	1
E01-5	11007-Z010110-0000	BOLT, DRAIN PLUG	2
E01-6	90408-Z010110-0000	WASHER	2
E01-7	90547-0205-CL	BEARING	1
E01-8	90682-Z300110-0000	SEAL, OIL	1
E01-9	90305-Z010210-01	NUT	1
E01-10	90408-Z010210-0000	WASHER	1
E01-11	90501-Z010110-0000	PIN	1
E01-12	90001-0614-01	BOLT	2


FIG.2 COVER SUBASSEMBLY, CRANKCASE (E02)




REF.NO.	PART NO	DESCRIPTION	Q'TY
E02-1	11411-Z010310-0000	COVER, CRANKCASE	1
E02-2	90547-0205-CL	BEARING	1
E02-3	90682-Z300110-0000	SEAL, OIL	1
E02-4	11001-Z010120-0000	GASKET, CRANKCASE	1
E02-5	90502-0812-00	PIN	2
E02-6	15010-Z010130-Q500	DIPSTICK SUBASSEMBLY, OIL	1
E02-8	15030-Z010130-Q500	PLUG SUBASSEMBLY, ENGINE OIL	1
E02-9	90001-0832-01	BOLT	6

FIG.3 HEAD SUBASSEMBLY, CYLINDER / PLUG,SPARK (E03)


REF.NO.	PART NO	DESCRIPTION	Q'TY
E03-4	12131-Z140120-0000	GASKET, CYLINDER HEAD	1
E03-5	12410-Z300120-0000	COVER SUBASSEMBLY, CYLINDER HEAD	1
E03-6	12004-Z010110-0000	GASKET, CYLINDER HEAD COVER	1
E03-7	17004-Z050210-0000	TUBE, BREATHER	1
E03-8	90001-0612-01	BOLT	4
E03-9	90204-Z010310-0000	STUD	2
E03-10	90203-Z010110-0000	STUD	2
E03-11	90502-1014-00	PIN	2
E03-12	12003-Z010110-0000	BOLT, CYLINDER HEAD	4
E03-13	30010-Z010110-0000	PLUG, SPARK	1
E03-14	12140-Z040610-0000	HEAD SUBASSEMBLY, CYLINDER	1

FIG.4 ROD,CRANKSHAFT CONNETING (E04)


REF.NO.	PART NO	DESCRIPTION	Q'TY
E04-1	13300-Z140330-0000	CRANKSHAFT ASSY.	1

FIG.5 RING SET,OIL / ROD,CRANKSHAFT CONNETING (E05)


REF.NO.	PART NO	DESCRIPTION	Q'TY
E05-1	13200-Z140210-0099	PISTON RING ASSY	1
E05-2	13122-Z010110-0000	CLIP, PISTON PIN	2
E05-3	13111-Z140220-0099	PISTON	1
E05-4	13121-Z010110-0000	PIN, PISTON	1
E05-5	13010-Z440210-0099	ROD, CONNECTING	1

FIG.6 TRAIN,VALVE / CAMSHAFT SUBASSEMBLY (E06)


REF.NO.	PART NO	DESCRIPTION	Q'TY
E06-1	14200-Z300210-0000	CAMSHAFT ASSY.	1
E06-2	12110-Z010110-0000	VALVES SET	1
E06-3	12112-Z010110-0000	SEAT, VALVE SPRING	1
E06-4	12107-Z010110-0000	RETAINER, EXHAUST VALVE	1
E06-5	12104-Z010110-0000	ROTATOR, VALVE	1
E06-6	12101-Z010110-0000	GUIDE, SEAL	1
E06-7	14081-Z040110-0000	TAPPET, VALVE	2
E06-8	14071-Z440110-0000	LIFTER, VALVE	2
E06-9	14090-Z010110-0000	PLATE SUBASSEMBLY, LIFTER STOPPER	1
E06-10	14313-Z010110-0000	BOLT, VALVE ADJUSTING	2
E06-11	14311-Z010110-0000	ROCKER, VALVE	2
E06-12	14314-Z010110-0000	NUT, VALVE ADJUSTING	2
E06-13	14312-Z010110-0000	NUT, VALVE LOCK	2
E06-14	12103-Z010110-0000	SPRING, VALVE	2

FIG.7 STARTER,RECOIL (E07)


REF.NO.	PART NO	DESCRIPTION	Q'TY
E07-1	90001-0608-01	BOLT	3
E07-2	28200-Z440110-H700	STARTER ASSY, RECOIL	1

FIG.8 SHROUD / SHIELD,LOWER (E08)


REF.NO.	PART NO	DESCRIPTION	Q'TY
E08-1	28110-Z010410-RW00	SHROUD	1
E08-2	19304-Z010710-0000	SHROUD, CYLINDER BODY	1
E08-3	19340-Z010120-0000	SHIELD, LOWER	1
E08-4	37050-Z010210-0000	PROTECTOR, OIL	1
E08-5	35540-Z060140-QG00	SWITCH SUBASSEMBLY, STOP ENGINE	1
E08-6	90001-0610-01	BOLT	2
E08-7	90001-0610-01	BOLT	1
E08-8	90740-Z010110-0000	COLLAR	1
E08-9	90001-0616-01	BOLT	1
E08-10	90001-0612-01	BOLT	4

FIG.9 CARBURETOR ASSY. (E09)

REF.NO.	PART NO	DESCRIPTION	Q'TY
E09-1	16100-Z040210-0000	CARBURETOR ASSY.	1
E09-2	17001-Z010210-0000	GASKET, AIR CLEANER	1
E09-3	16001-Z010110-0000	GASKET, CARBURETOR	1
E09-4	16003-Z010110-0000	PLATE, CARBURETOR INSULATOR	1
E09-5	16002-Z010110-0000	GASKET, CARBURETOR INSULATOR	1


FIG.10 FLYWHEEL / IMPELLER / STARTER PULLEY / IGNITION COIL (E10)

REF.NO.	PART NO	DESCRIPTION	Q'TY
E10-1	13501-Z010110-0000	NUT, FLYWHEEL	1
E10-2	28002-Z010310-0000	PULLEY, STARTER	1
E10-3	19352-Z010110-0000	IMPELLER	1
E10-4	13510-Z010110-0000	FLYWHEEL SUBASSEMBLY	1
E10-5	30400-Z440110-0000	COIL, IGNITION	1
E10-6	90001-0625-01	BOLT	2

FIG.11 CONTROL ASSY, THROTTLE (E11)


REF.NO.	PART NO	DESCRIPTION	Q'TY
E11-1	16520-Z010230-0000	CONTROL ASSY, THROTTLE	1
E11-2	16063-Z010110-0000	SPRING, GOVERNOR	1
E11-3	16062-Z010110-0000	ROD, GOVERNOR	1
E11-4	16012-Z010110-0000	SPRING, THROTTLE VALVE RETURNING	1
E11-5	16070-Z010110-0000	SUPPORT SUBASSEMBLY, GOVERNOR	1
E11-6	90001-0610-01	BOLT	2
E11-7	16072-Z010110-0000	BOLT, GOVERNOR SUPPORT	1
E11-8	90305-0600-31	NUT	1

FIG.12 CLEANER, AIR (F01)




REF.NO.	PART NO	DESCRIPTION	Q'TY
F01-1	17100-Z010210-0000	CLEANER, AIR	1
F01-2	90305-0600-31	NUT	2

FIG.13 MUFFLER ASSY. (F02)




REF.NO.	PART NO	DESCRIPTION	Q'TY
F02-1	18001-Z010110-0000	GASKET, EXHAUST OUTLET	1
F02-2	90303-0800-31	NUT	2
F02-3	18100-Z011310-H300	MUFFLER ASSY	1

FIG.14 TANK ASSY, FUEL (F03)




REF.NO.	PART NO	DESCRIPTION	Q'TY
F03-1	16620-Z440120-RW00	TANK, FUEL	1
F03-2	16652-Z010610-0000	STRAINER, FUEL	1
F03-3	16730-Z010820-QB00	COVER, FUEL TANK	1
F03-4	16680-Z010110-0000	OUTLET SUBASSEMBLY, FUEL TANK OIL	1
F03-5	90740-Z010210-0000	CLAMP	2
F03-6	90686-Z010510-0000	TUBE, FUEL	1
F03-7	90001-0630-01	BOLT	1
F03-8	90305-0600-31	NUT	2
F03-9	30431-Z010110-0000	JACKET, RUBBER	1

15: (F61)



REF.NO.	PART NO	DESCRIPTION	Q'TY
F61-1	70400-V270110-0000	HOOP SUBASSEMBLY, HOSE	3
F61-2	90752-V090510-0000	JOINT, WATER TUBE	1
F61-3	70135-V090210-0000	STRAINER	1
F61-4	70123-V090410-0000	BOLT	6
F61-6	70107-V260210-0000	PLUG, THREAD	2
F61-7	70122-V260110-0000	WASHER, SCREW PLUG	2
F61-8	70105-V090610-0K00	PUMP BODY	1
F61-9	70115-V090410-0000	GASKET, INLET WATER	1
F61-10	70103-V090410-0000	CASE, WHORL	1
F61-11	70104-V090410-0000	RIGN, WHORL CASE SEALING	1
F61-12	90001-V070110-01	BOLT	5
F61-13	90409-V260110-0000	GASKET	1
F61-14	70102-V090410-0000	IMPELLER, WATER PUMP	1
F61-15	90522-V020110-0000	KEY	1
F61-16	70125-V260210-0000	WASHER	1
F61-17	70309-V330110-0000	SEAL, PORCELAIN	1
F61-18	70300-V330110-0000	SEAL ASSY, MECHANISM	1
F61-20	70119-V090410-0000	CUSHION, WATER PUMP JOINT	1
F61-21	90409-V260110-0000	WASHER	4
F61-23	90505-0618-00	PIN	1
F61-24	70118-V090410-0K00	JOINT, WATER PUMP	1
F61-25	70131-V270110-0000	RING, HOSE JOINT SEAL	2
F61-26	70112-V270310-0K00	INTERFACE, HOSE	2
F61-27	70111-V270310-0K00	JOINT, HOSE	2
F61-28	70100-V090910-0K00	PUMP ASSY, WATER	1

FIG.16 FRAME ASSY, ENGINE (F04)



REF.NO.	PART NO	DESCRIPTION	Q'TY
F04-1	51100-V091410-H7L0	FRAME ASSY, ENGINE(BLACK)	1
F04-2	90001-0610-01	BOLT	4
F04-3	51014HY450110-0000	SEAT, ENGINE FRAME SHOCK ABSORPTION	4
F04-4	90001-0850-01	BOLT	4
F04-5	90327-0800-31	NUT	4
F04-6	90327-0800-31	NUT	2
F04-7	90406-0800-E1	WASHER	2
F04-8	90001-0835-01	BOLT	2