




LP	Nazwa	Kod	Ilość
1	Base/cover of pipe base socket	581595	5
2	Screw	580690	1
3	Screw	581596	4
4	Aluminum tube-casing end	581597	1
5	Internal Conductor	581598	1
6	Duct bottom	581599	1
7	Duct cover	581600	1
8	Tension KNOB	580691	1
9	Support Block	580692	1
10	Tension Spring	580693	1
11	Tension Block	580694	1
12	Lock the base	580695	1
13	Torsion spring	580696	1
14	Tension KNOB cover	580697	1
15	Elastic Pin	581601	1
16	Screw	581602	1
17	Front cover	580698	6
18	Tension wheel	580699	1
19	Tension Plate	580700	1
20	Guide plate	580701	1
21	Screw	581603	1
22	Chain	580702	1
23	Knife sleeve	580703	1
24	Snap Spring	581604	2
25	Sprocket	580704	1
26	Gaskets	581605	1
27	Outlet seal	581606	1
28	Strong magnetism	581607	1
29	Chassis bottom	581608	1
30	Bottom of gear box	581609	1
31	Combination screw	581610	2

LP	Nazwa	Kod	Ilość
32	6000Z high speed bearing	580705	2
33	Output Shaft	580706	1
34	Semicircle key	581611	1
35	Big Gear	580707	1
36	Snap Spring	581612	1
37	Gearbox cover	581613	1
38	Oil pump worm gear	580708	1
39	Valve rubber	581614	1
40	Oil Pot	580709	1
41	Oil Pump	580710	1
42	φ3*φ5.5	581615	1
43	φ3*φ5.5	581616	1
44	Case cover	581617	1
45	Screw	581618	11
46	Oil Pot cover lanyard assembly	580711	1
47	O-ring	580712	1
48	Cylindrical Pin		
49	Oil Pot cover		
50	Tower Spring		
51	Oil Pan cover plate		
52	Motor Tooth	580713	1
53	699Z plain bearing	580714	1
54	Pressure Plate	581619	1
55	Axle collar	581620	1
56	Dongchang District up to 785 motor (18V round	580715	1
57	INDUCTOR assembly	581621	1
58	Aluminum Tube base	580716	1
59	Socket socket	580717	1