






Lp	Kod	Nazwa	Ilość
1	071300	10" Guide board	1
2	071301	Chain	1
3	071302	Tank cap ass'y	1
4	071303	BOLT M5X20	3
5	071304	Oil tank	1
6	071305	Gear case	1
7	071306	Oil cup M6	1
8	071307	Stop ring 28	1
9	071308	Left pinion	1
10	071309	Bearing 6001/P5	1
11	071310	Bearing 6001-2RS/P5	1
12	071311	Stop ring 12	1
13	071312	BOLT M5X25	1
14	071313	Bolt M5x12	1
15	071314	Bearing 627-Z	1
16	071315	Right pinion	1
17	071316	Bearing 6002-2RS/P5	1
18	071317	Gear case cover	1
19	071318	Filter	1
20	071319	Screw M5X16	3
21	071320	Worm	1


22	071321	Worm wheel ass'y	1
23	071322	Screw M4X10	2
24	071323	Pusher	1
25	071324	Baffle	2
26	071325	Chain wheel	1
27	071326	Washer	3
28	071327	Screw	1
29	071328	Nut M6	2
30	071329	Bolt	2
31	071330	Cover Borad Comp	1
32	071331	Adjust pin	1
33	071332	Driven gear	1
34	071333	Driving gear	1
35	071334	Gear cover	1
36	071335	Connecting pipe	1
37	071336	Lube pipe(out)	1
38	071337	Lube pipe(in)	1
39	071338	ST 2.9X7.5	1





Lp	Kod	Nazwa	Ilość
B		Front Shaft Ass'y	1
1	071339	Front Pipe	1
2	071340	Lip Block	1
3	071341	Stop ring 15	1
4	071342	Shaft Sleeve I	1
5	071343	Bearing Ass'y	1
6	071344	Rivet 4x8	3
7	071345	Washer	2
8	071346	Joint	1
9	071347	Rubber Plug	1
10	071348	Front Shaft	1
11	071349	Front Shaft Bracing	1



Lp	Kod	Nazwa	Ilość
C	071350	Connecting Sleeve Ass;y	1
1	071351	Connecting Sleeve Ass;y	1
2	071352	Handle	1
3	071353	Screw M5x25	2
4	071354	Reducing sleeve	1




Lp	Kod	Nazwa	Ilość
D	071355	Back Shaft Ass'y	1
1	071356	Connecting Sleeve 1	1
2	071357	Bearing Ass'y 4	4
3	071358	Rivet 4X8 2	2
4	071359	Washer 4 2	2
5	071360	Shaft Sleeve II 4	4
6	071361	I Thin Pipe 1	1
7	071362	Back Shaft Bracing 1	1
8	071363	Back Shaft 1	1
9	071364	Damping Shaft 1	1
10	071365	Rubber Plug 1	1
11	071366	Joint 1	1
12	071367	Screw M5X25 2	2
13	071368	Screw M6X25 2	2
14	071369	Thick Pipe 1	1
15	071370	Rubber Cover 1	1



Lp	Kod	Nazwa	Ilość
F	071391	Holder Ass'y	1
1	071392	Harness Clamp	1
2	071393	Clamp	1
3	071394	Screw M5x20	1
4	071395	Nut M5	1
G	071396	Harness Ass'y	1

The Parts List of Model 1E34F-3E Engine



Lp	Kod	Nazwa	Ilość
1	071408	Screw	1
2	071409	OUTSIDE COVER	1
3	071410	FILTER NET	1
4	071411	BAFFLE	1
5	071412	SCREW M5X60	2
6	071413	SCREW M5X12	2
7	071414	BAFFLE	1
8	071415	Inside Cover	1
9	071416	CARBURETOR	1
10	071417	GASKET	1
11	071418	SCREW M5X25	1
12	071419	Pipe	1
13	071420	ADMITTING PIPE	1
14	071421	GASKET	2
15	071422	REED VALVE	1
16	071423	SCREW M5X14	1
17	071424	GASKET	3
18	071425	GUARD COVER ASS'Y	1
19	071426	SCREW M5X18	4
20	071427	CYLINDER	1
21	071428	SPARK PLUG	1

22	071429	GASKET	1
23	071430	PISTON RING	2
24	071431	PISTON	1
25	071432	GASKET	1
26	071433	MUFFLER COMP.	1
27	071434	SCREW M5X65-10.9	2
28	071435	SCREW M4X20	2
29	071436	STARTER COMP.	1
30	071437	STARTER REEL	1
31	071438	REAR HALF CRANK CASE	1
32	071439	PISTON PIN CIRCLIP	2
33	071440	PISTON PIN	1
34	071441	NEDDLE BEARING	1
35	071442	PIN 4 h8X10	2
36	071443	CRANKE SHAFT COMP.	1
37	071444	GASKET	1
38	071445	SCREW M5X12	1
39	071446	BALL BEARING 6001/P6	2
40	071447	CRANKE CASE GASKET	1
41	071448	FRONT HALF CRANKE C	1
42	071449	PIN 4 h8X10	1
43	071450	SCREW M4X20	2
44	071451	OIL SEAL	3
45	071452	FLY WHEEL	2
46	071453	NUT M8	1
47	071454	IGNITION COIL COMP.	1
48	071455	SCREW M5X20	2
49	071456	FAN COVER	
50	071457	SCREW M5X18	2
51	071458	Washer	2
52	071459	EXPANDER	
53	071460	Washer	2
54	071461	CLUTCH STEP SCREW	2
55	071462	CLEANER COVER	1
56	071463	Plug	1
57	071464	FUEL PIPE	1
58	071465	FUEL PIPE	1
59	071466	FUEL TANK	1
60	071467	SCREW M5X16	2
61	071468	BRACKET	1
62	071469	Fuel Tank Lid COMP.	1
68	071470	SCREW M5X25	2
69	071471	BRACKET	1
70	071472	SCREW M4X25	1
71	071473	SCREW M5X25	2
72	071474	CORD COMP.	1