




Lp	Kod	Nazwa	Ilość
1	971078	quick hitch	1
2	971079	needle bearing	1
3	971080	needle bearing	1
4	971081	screw	2
5	971082	screw	2
6	971083	layer	1
7	971084	plate	1
8	971085	screw	4
9	971086	connector	1
10	971087	claw shaft	1
11	971088	screw	3
12	971089	bearing	1
13	971090	seal ring	1
14	971091	gearbox	1
15	971092	gearbox shield	1
16	971093	reinforcement	1
17	971094	flat gasket	18
18	971095	screw	14
19	971096	needle bearing	1
20	971097	pressure relief bolt	1
21	971098	flat key	1
22	971099	properller shaft	1
23	971100	square gasket	1
24	971101	gear box support	1
25	971102	adjust shaft, pin	1
26	971103	spring	1
27	971104	cover seat	1
28	971105	bolt	1
29	971106	nut	10
30	971107	cirlip for shaft	1
31	971108	spring	1
32	971109	reversing lever	1
33	971110	nut	25
34	971111	pin	1
35	971112	spring	1
36	971113	reversing handle	1
37	971114	button	1
38	971115	rubber cover	1
39	971116	cirlip	1
40	971117	nut	10
41	971118	right plate	2
42	971119	right drill	1
43	971120	screw	8
44	971121	blade bit	8
45	971122	screw	8
46	971123	right blade	4

Lp	Kod	Nazwa	Ilość
47	971124	wheel	1
48	971125	wheel support	1
49	971126	cotter pin	1
50	971127	insert pin	1
51	971128	flat key	2
52	971129	32 bevel gear	1
53	971130	flat key	1
54	971131	output shaft	1
55	971132	screw	4
56	971133	bearing	2
57	971134	seal ring	2
58	971135	gearbox cover	1
59	971136	dust cotton	2
60	971137	washer	6
61	971138	fixing frame	1
62	971139	gearbox cover shield	1
63	971140	screw	14
64	971141	left blade	4
65	971142	screw	16
66	971143	left plate	2
67	971144	left drill	1
68	971145	thickening pad	2
69	971146	washer	2
70	971147	screw	2
71	971148	drag head	2
72	971149	back bumper	1
73	971150	left bumper	1
74	971151	flat	4
75	971152	screw	2
76	971153	left and right shield	2
77	971154	middle shield	1
78	971155	screw	3
79	971156	right bumper	1